

BAIL FITTING INSTRUCTIONS

BAIL WELDED TO LOCKING TIP:

- Bails may be Tig, Mig, or Arc welded; brazed, or silver soldered

BAIL ATTACHED VIA ROLL PIN:

- To use enclosed roll pin, use 5/64" drill bit and drill through rod, using recessed hole as guide. Insert roll pin. Pin may be driven out for service. Ensure rod is inserted the full 1/2" depth of the locking tip hole.

